


# PNI CommBoard (RS-232, RS-485)

## General Description

The CommBoard is a communication interface designed to connect the MicroMag and V2Xe modules to a host system that uses a standard serial interface, such as a PC. It is typically used as a prototyping and evaluation tool for PNI's line of compass and magnetometer modules. The PNI CommBoard is also used for production when the host system requires a higher level serial protocol to interface to the PNI sensor modules. The first version of the PNI CommBoard features a user selectable RS-232 or RS-485 interface to the host system. The CommBoard developer kit comes with software for the PC that has a graphical user interface (GUI) to control every aspect of the CommBoard and any PNI module that is attached to it.

In the future, different interfaces may be made available as customer needs are identified. Please contact PNI for support with your custom interface high-volume opportunity.



## Features

- Small size: 53 x 25 x 11 mm
- RS-232 and RS-485 interfaces for connection with PCs or other serial interface systems
- GUI control software available from PNI, either as part of the developer kit or via the web
- Built-in support for PNI MicroMag and V2Xe sensor modules, as well as several future products
- Voltage regulator converts 6 - 12 VDC to 3 VDC for power to the sensor modules
- Minimal code changes required when upgrading from PNI's TCM-2 line of tilt compensated magnetometer compass modules

## Applications

- Fast compass and magnetometer prototyping
- New product evaluation
- Education, school projects
- Any legacy compass application that has an RS-232 interface but needs the performance of new PNI products
- Production applications where standards based protocols are preferred over SPI.

## Ordering Information

Name	Part #	Package
CommBoard Kit (with cable & software)	90009	Each

Table 1

*This page left intentionally blank*

## SPECIFICATIONS

### CAUTION:

Stresses beyond those listed under **Table 2: Absolute Maximum Ratings** may cause permanent damage to the device. These are stress ratings only. Functional operation of the device at these or any other conditions beyond those indicated in the operational sections of the specifications is not implied. Exposure to absolute maximum rating conditions for extended periods may affect device reliability.

**Table 2: Absolute Maximum Ratings**


Symbol	Parameter	Minimum	Maximum
V <sub>DD</sub>	DC supply voltage	-0.3 VDC	16 VDC
V <sub>IN</sub>	Input pin voltage (CTS, RxD) to ground	-25 VDC	25 VDC
	Input pin voltage (TxD, RTS) to ground	-13.2 VDC	13.2 VDC
	Input pin voltage (D+, D-) to ground	-13.2 VDC	13.2 VDC
T <sub>STRG</sub>	Storage Temperature	-40°C	85°C

**Table 3: Characteristics**

Parameter	Minimum	Maximum	Typical
<b>Operating Characteristics</b>			
Current – standby (Low power mode, no module loaded)			
LPM0 <sup>a</sup>			14.4 mA RMS
LPM1 <sup>b</sup>			7.0 mA RMS
LPM2 <sup>c</sup>			5.4 mA RMS
<b>RS-232 Receiver Inputs (CTS, RxD)</b>			
Input threshold low	0.6 VDC		
Input threshold high		2.0 VDC	
<b>RS-232 Transmitter Output (TxD)</b>			
Output Voltage Swing (both transmitter outputs loaded with 3K $\Omega$ to GND)	$\pm 5$ VDC		$\pm 5.4$ VDC
Output resistance (V <sub>CC</sub> = V <sub>+</sub> = V <sub>-</sub> = 0, output = 2 V)	300 $\Omega$		10M $\Omega$
Output short circuit current (Output = GND)		$\pm 60$ mA	$\pm 30$ mA
<b>RS-485 Transceiver Signals (D-, D+)</b>			
Input differential threshold	-200 mVDC	-50 mVDC	
Differential output voltage (R = 27 $\Omega$ )	1.5 VDC		
Change in magnitude of differential output voltage for complementary output states (R = 27 $\Omega$ or 50 $\Omega$ )	-0.2 VDC	0.2 VDC	
Common mode output voltage (R = 27 $\Omega$ or 50 $\Omega$ )		3.0 VDC	
Change in magnitude of common mode output voltage for complementary output states (R = 27 $\Omega$ or 50 $\Omega$ )		0.2 VDC	
Output sort-circuit current (V <sub>Y</sub> or V <sub>Z</sub> = +12 V to - 7 V)		$\pm 250$ mA	

- a. The unit is in normal operating mode with the LEDs enabled.
- b. The unit is in normal operating mode with the LEDs disabled.
- c. The unit is in a Sleep mode and will need to be awakened via the CTS (Wake Up) line.

## Serial Pin Descriptions



**Figure 1: Jumpers and Connectors**

**Table 4: Serial Pin Descriptions (J1)**

Pin	Name	Function
1	TxD	RS-232 transmitter output (transmitted data)
2	Reserved	RS-232 transmitter output (reserved)
3	n/c	not connected
4	RxD	RS-232 receiver input (received data)
5	D-	RS-485 transceiver signal (inverting RS-485 signal)
6	D+	RS-485 transceiver signal (non-inverting RS-485 signal)
7	n/c	not connected
8	GND	Ground
9	VCC	Supply voltage (5 to 12 VDC)
10	GND	Ground

## RS-232 and RS-485 Jumper Settings

**Table 5: Jumper Configuration**

Configuration	Mode
JMP1 installed <sup>a</sup>	RS-232
JMP1 removed <sup>a</sup>	RS-485
JMP2 installed <sup>b</sup>	RS-485; 120 Ω line termination
JMP2 removed <sup>b</sup>	RS-485; no line termination

- The processor only checks the status of JMP1 at power up. IF the position of the jumper needs to be changed, either cycle the power or press the RESET switch after the change has been made.
- JMP2 must only be installed on the last unit of the network. All other units need to have JMP2 removed for proper RS-485 operation.

## *Serial Pin Descriptions (cont).*

**Table 6: Connector J2**

<b>Pin</b>	<b>Function</b>	<b>I/O Direction</b>
1	SCLK	Output
2	MISO	Input
3	MOSI	Output
4	SSNOT	Output
5	DRDY	Input
6	SYNC	Output
7	GND	
8	GIO0	Output low
9	GIO1	Output low
10	GIO2	Output low
11	GIO3	Output low
12	VDD	
13	VCC	
14	GGND	

## Hardware Modes

The CommBoard provides a serial interface to PNI's sensor modules. Its purpose is to translate a serial command from a host system into the appropriate SPI command. If the sensor module does not support the command, it will return the appropriate error code. Otherwise, it will return the associated data. See the applicable PNI module data sheet for specific information on communication and control using the SPI interface.

- RS-232 mode uses software handshaking to communicate.
  - Xon = ^Q = 0 x 11 (okay to send data)
  - Xoff = ^S = 0 x 13 (stop sending data)
- RS-485 mode is only Half-Duplex.
  - The Continuous Output (**go**) command is not allowed since Half-Duplex implies queried responses only.
  - The CommBoard acts as a Slave when the JMP1 is removed.

### Example

```
!FF00$C194.74X-106.00Y-403.00Z98.00:E200*1E
!DdSs${data}* <dc><es>
```

**Table 7: Hardware Modes**

!	RS-485 data delimiter
Dd	Destination address
Ss	Source address
\$	Start data delimiter
{data}	Selected data output
*	End data delimiter
<dc>	Checksum
<es>	End of message based on eol variable <cr> or <lf> or <cr><lf>

### NOTE:

The query and response format must match. All examples in this manual show the query and response of the RS-232 mode. When using RS-485 just add the RS-485 data delimiter, destination address, source address and checksum, to the examples shown.

### Checksum

The CommBoard uses a XOR checksum method from the beginning of the string up to, but not including, the end data delimiter (“\*”). Examples:

	RS-232	RS-485
Sent Command	id? (no checksum required)	!00ff\$id?*37
Reply	\$id=3*27	!00ff\$id?*06

## Standard Data Output Modes

### PNI Standard Output Mode (sdo=t)

The PNI Standard Output Mode may be configured to provide all sensor data availability, or only the data you require.

**EXAMPLE:**

```
$C194.74X-106.00Y-403.00Z98.00:E200*1E
${data}* <dc><es>
```

**Table 8: Standard Output Modes**

\$	Start data delimiter
{data}	Selected data output
*	End data delimiter
<dc>	Checksum up to but not including “*”
<es>	End of message based on eol variable <cr> or <lf> or <cr><lf>

### NMEA Output Mode (National Marine Electronics Association ) (sdo=n)

The NMEA Output mode conforms to the 0183 specification. In this mode, only compass heading information is available.

**EXAMPLE:**

```
$HCHDM,71.33,M*2F
$HC<sid>,{data},<dt>* <dc><es>
```

**Table 9: NMEA Output Modes**

\$	Start data delimiter
HC	Heading compass (magnetic), Talker ID
<sid>	Heading magnetic = HDM, heading true = HDT, Sentence ID
71.33	Heading degrees
<dt>	Data type M = magnetic, T = true
*	End data delimiter
<dc>	Checksum
<es>	End of message based on eol variable <cr> or <lf> or <cr><lf>

## Raw Output Mode (sdo=r)

The Raw Output mode allows for the output of the raw, uncorrected data for any or all of the required sensors. The Raw Output Mode is the only mode where Z-Axis is active.

### **EXAMPLE:**

```
$raw,X53Y-420Z0*6E  
$raw,{data}*<dc><es>
```

**Table 10: Raw Output Modes**

\$	Start data delimiter
{data}	Selected data output
*	End data delimiter
<dc>	Checksum
<es>	End of message based on eol variable <cr> or <lf> or <cr><lf>

**NOTE:** For modules with a Z-axis when used in other modes than raw, Z-axis is turned off and module is run as a Z-axis system since no tilt compensation is being done.

## Command Line Interface

The Command Line interface allows you to use a simple terminal program to communicate with the CommBoard. The Command Line interface also allows applications written in any language, including Assembly, Basic, or C to communicate with the CommBoard via the RS-232 or RS-485.

### Command Sequence

The sequence of command line events is:

1. Type in the command on the terminal program: `cmd?<es>`
2. The module processes the command.
3. A reply is sent back to you.
  - a. If no error `$cmdreply*<dc><es>`
  - b. If error `$cmdreply:Exxx*<dc><es>`

**Table 11: Command Notation Table**

Command Symbol	Response Symbol	Description
?		Indicated query only command or variable
=		Indicates assign only command or variable
<aq>		Use ? for query or =<val> for assign
<es>		Ending sequence <cr> or <lf> or <cr><lf>
	\$	Start of checksum data
	!	RS-485 address follows
	:	If error occurs; :Ennn
	*	End of checksum data
	<dc>	Checksum
	<er>	Start of data
n	n	Usually a lower case 'n' will represent a digit (0-9)
n.n	n.n	Represents a decimal value (positive or negative)
x	x	Usually a lower case 'x' will represent a hex digit (0-F)
xx	xx	Represents a Uint8
xxxx	xxxx	Represents a Uint16
xxxxxxxx	xxxxxxxx	Represents a Uint32

a. XOR checksum method.

### Example Command Notation

m<aq><es>

This will be interpreted as a query: em?<es>

This will be interpreted as assignment: em=<val><es>

### Example Response Notation

\$em=<val>\*<dc><er>

### Ending Sequence

The CommBoard will accept either <cr> or <lf> or <cr><lf> as an end of line (eol) indicator.

### *EOL (end of line) Response*

The CommBoard will send a response to you in the chosen EOL format.

If (eol=cr)	Send (“\r”)
If (eol=lf)	Send (“\n”)
If (eol=crlf)	Send (“\r\n”)

## Error Codes

Error codes are a bitmap to the error that has occurred and are sent when an error condition has occurred.

### Example

```
$C194.74X-106.00Y-403.00Z98.00:E200*1E  
$Cnnn.nnXnnn.nnYnnn.nnZnnn.nn:Exxx*<dc><er>
```

**Exxx:** “xxx” are hex values between 0 - F.

The built-in error command to parse error messages, error ffff<cr><lf>, will list the error codes.

**Table 12: Error Codes**

Code	Description
E800	EEPROM1 error <sup>a</sup>
E400	EEPROM2 error <sup>a</sup>
E200	Module not calibrated <sup>b</sup>
E100	Module not capable
E080	Internal error
E040	Command parameter invalid
E020	Command/data mode conflict
E010	Command invalid or unavailable
E008	Module not found
E004	Magnetometer out of range
E002	Inclinometer out of range
E001	Magnetic distortion alarm

- a.** Indicates a possible problem with the unit. Please contact PNI Corporation
- b.** A compass heading of -1.00 will be output when the module is not calibrated. \$c-1.00:E200
- c.** Indicates that the magnetic field has changed significantly since the last calibration. See the specific module data sheet for the parameter range.

## ACTION COMMANDS

### factory (Factory Settings Restore)

Restores the CommBoard and modules to the factory default configuration.

**Syntax:** factory<es>

**Response Format:** \$factory\*<dc><er>

### go (Continuous Output)

Instructs the CommBoard to enter continuous mode. The CommBoard will begin sampling sensors at the rate specified by the Polling Frequency (**pollfreq**) command.

**Syntax:** go<es>

**Response Format:** \$(select data)\*<dc><er>

**Notes:** Stopped using the **h** command

### h (Halt Continuous Output)

Instructs the CommBoard to exit the continuous output mode.

**Syntax:** h<es> if halt = d *see halt command*  
h if halt = e

**Response Format:** \$h\*<dc><er>

### help or ? (Help Menu)

Instructs the CommBoard to display the Help menu.

**Syntax:** help<es> or ?<es>

**Response Format:** Menu Data

### id? (Module Identification)

Displays the module type. IF the MicroMag responds with either 01 or 02, contact PNI Corporation as there could possibly be a damaged or unconnected sensor.

**Syntax:** id?<es>

**Response Format:** \$id=xx\*<dc><er>

<b>Valid Values:</b>	xx = 00	None
	xx = 01	MicroMag (X sensor only)
	xx = 02	MicroMag (Y sensor only)
	xx = 03	MicroMag (X and Y sensors)
	xx = 07	MicroMag (X, Y and Z sensors)
	xx = 10	V2Xe

### info? (Module Information)

Displays the CommBoard software version, module type, and module software version, if applicable.

**Syntax:** info?<es>

<b>Response Format:</b>	\$info,PNI-commboard Vnnn*<dc>	CommBoard
	info, {module info}*<dc>	Module

## QUERY COMMANDS

### c? (Compass Update)

Retrieves the compass heading. Based upon the setting for the Data Output Forma (**sdo**) command and the Compass Units (**uc**) command. Refer to “pollfreq” on page 21.

*Note: For modules that do not have an onboard processor (for example, the MicroMag), the CommBoard will calculate and output this data*

**Syntax:** c?<es>

**Response Format:** \$c{hdg}\*<dc><er>

**Valid Values:** hdg = 0 to 359.99 if uc = d  
hdg = 0 to 6399 if uc = m

### error x (Error Code List)

Retrieves a description of the error code entered from the CommBoard. Refer to “Error Codes” on page 11.

**Syntax:** error x<es>  
error ffff<ex>

**Response Format:** \$error x: (description) \*<dc><er>

**Valid Values:** x the error number following the “E” in the response string  
ffff lists all error codes

### m? (Magnetometer Update)

Retrieves the corrected X, Y, and Z axis magnetometer data. Corrected data is that which is used to calculate heading. The Z sensor output is not available on all modules. Refer to the specific module data sheet for more information.

*Note: For modules that do not have an onboard processor (for example, the MicroMag), the CommBoard will calculate and output this data*

**Syntax:** m?<es>

**Response Format:** \$Xn.nYn.nZn.n\*<dc><er>

**Valid Values:** xn.n

### s? (Single Sample Update)

Retrieves the user selected calibration information. Based upon the settings of the various Configuration commands

*Note: For modules that do not have an onboard processor (for example, the MicroMag), the CommBoard will calculate and output this data*

**Syntax:** s?<es>

**Response Format:** \${selectedData}\*<dcs><er>

**Valid Values:** selectedData varies according to user settings

### sr? (Single Raw Sample Update)

Retrieves the raw data (uncorrected ASIC output) for the sensors selected. For example, X, Y, and Z axis magnetometers. The Z sensor output is not available on all modules. Refer to the specific module data sheet for more information

**Syntax:** sr?<es>

**Response Format:** \${selectedRawData}\*<dcs><er>

**Valid Values:** selectedRawData varies according to user settings

### t? (Temperature Update)

Retrieves the temperature value. Outputs are based on the setting of the Temperature Units (**ut**) command. The temperature output is not available in all modules. Refer to the specific data sheet for more information.

**Syntax:** t?<es>

**Response Format:** \$Tn.n\*<dcs><er>

**Valid Values:** \$Tn.n the calibrated temperature sensor output

## x? (X Axis Sensor Update)

Retrieves only the corrected X axis magnetometer values used for heading calculation.

*Note: For modules that do not have an onboard processor (for example, the MicroMag), the CommBoard will calculate and output this data*

**Syntax:** x?<es>

**Response Format:** \$Xn.n\*<dcs><er>

**Valid Values:** n.n

## y? (Y Axis Sensor Update)

Retrieves only the corrected Y axis magnetometer values used for heading calculation.

*Note: For modules that do not have an onboard processor (for example, the MicroMag), the CommBoard will calculate and output this data*

**Syntax:** y?<es>

**Response Format:** \$Yn.n\*<dcs><er>

**Valid Values:** n.n

## CONFIGURATION COMMANDS

### b (Baud Rate)

Sets the baud rate of the CommBoard

**Syntax:** b<aq><es>

**Response Format:** \$b={value}\*<dcs><er>

**Valid Values:** Table 13

0 = 300	5 = 9600(default)
1 = 600	6 = 19200
2 = 1200	7 = 38400
3 = 2400	8 = 57600
4 = 4800	

**Query Syntax:** b?<es>

### ec (Compass Data Enable)

Enables the compass data output

*Note: For modules that do not have an onboard processor (for example, the MicroMag), the CommBoard will calculate and output this data*

**Syntax:** ec<aq><es>

**Response Format:** \$ec={value}\*<dcs><er>

**Valid Values:**  
e = enabled (default)  
d = disabled

**Query Syntax:** ec?<es>

## echo (Echo Characters Enable)

Enables character echo, which directs the CommBoard to echo locally typed characters onto the display

**Syntax:** echo<aq><es>

**Response Format:** \$echo={value}\*<dcs><er>

**Valid Values:** e = enabled  
d = disabled (default)

**Query Syntax:** echo?<es>

## em (Magnetometer Data Enable)

Enables all of the magnetometer data output. For example, em=e will set ex=e, ey=e and ez=e.

*Note: If any axis is disabled after em=e, em? will still respond with em=e. Z-axis is only active in raw mode.*

**Syntax:** em<aq><es>

**Response Format:** \$em={value}\*<dcs><er>

**Valid Values:** e = enabled  
d = disabled (default)

**Query Syntax:** em?<es>

## eol (End of Line Enable)

Sets the type of end of line output

**Syntax:** eol<aq><es>

**Response Format:** \$eol={value}\*<dcs><er>

**Valid Values:** cr = output cr after line  
lr = output lr after line  
crlf = output crlf after line (default)

**Query Syntax:** eol?<es>

### et (Temperature Data Enable)

Enables the temperature data output. Temperature output is not available on all modules. Refer to the specific module data sheet for more information.

**Syntax:** et<aq><es>  
**Response Format:** \$et={value}\*<dc><er>  
**Valid Values:** e = enabled  
d = disabled (default)  
**Query Syntax:** et?<es>

### ex (X Axis Data Enable)

Enables the X-axis data output.

**Syntax:** ex<aq><es>  
**Response Format:** \$ex={value}\*<dc><er>  
**Valid Values:** e = enabled  
d = disabled (default)  
**Query Syntax:** ex?<es>

### ey (Y Axis Data Enable)

Enables the Y-axis data output.

**Syntax:** ey<aq><es>  
**Response Format:** \$ey={value}\*<dc><er>  
**Valid Values:** e = enabled  
d = disabled (default)  
**Query Syntax:** ey?<es>

## ez (Z Axis Data Enable)

Enables the Z-axis data output. The Z sensor output is not available on all modules. Refer to the specific module data sheet for more information. Z-axis is only active in raw mode.

**Syntax:** ez<aq><es>

**Response Format:** \$ez={value}\*<dcs><er>

**Valid Values:** e = enabled  
d = disabled (default)

**Query Syntax:** ez?<es>

## halt (Single Character Halt Enable)

Enables sending a single Halt (**h**) command to cancel the Continuous Output (**go**) mode.

**Syntax:** halt<aq><es>

**Response Format:** \$halt={value}\*<dcs><er>

**Valid Values:** e enabled; h (default)  
d disabled; h<es>

**Query Syntax:** halt?<es>

## lpm (Low Power Mode)

Selects the low power mode for the CommBoard. Once set to lpm=2, the CommBoard will “wake” from ultra low power and go into lpm=0 when it receives a character over the RS-232 interface. **Table 3** on page 4 lists the current draw at the different lpm levels.

**Syntax:** lpm<aq><es>

**Response Format:** \$lpm={value}\*<dcs><er>

**Valid Values:** 0 no conversion (default)  
1 LEDs off  
2 ultra low power

**Query Syntax:** lpm?<es>

### pollfreq (Polling Frequency)

Sets the sample polling frequency of the Continuous Output (**go**) command.

**Syntax:** pollfreq<aq><es>

**Response Format:** \$pollfreq=nn\*<dcs><er>

**Valid Values:** nn 0 = 1 sample/2 seconds  
1 – 16 = value in Hz (default is 8)

**Query Syntax:** pollfreq?<es>

### rs485 (RS-485 Slave Address)

Sets the slave address for the CommBoard in RS-485 mode.

**Syntax:** rs485<aq><es>

**Response Format:** \$rs485=xx\*<dcs><er>

**Valid Values:** xx 00 to 7F (default is 00)

**Query Syntax:** rs485?<es>

### sdo (Data Output Format)

Sets the data output format to PNI standard, NMEA, or RAW. Refer to “**Standard Output Modes**” on page 8 for more information.

**Syntax:** sdo<aq><es>

**Response Format:** \$sdo={value}<dcs><er>

**Valid Values:** t PNI standard format (default)  
n NMEA 0183 compatible format  
r raw output format (uncorrected from sensors)

**Query Syntax:** sdo?<es>

## uc (Compass Units)

Sets the compass output to either degrees or mils.

*Note: For modules that do not have an onboard processor (for example, the MicroMag), the CommBoard will calculate and output this data*

**Syntax:** uc<aq><es>

**Response Format:** \$uc={value}\*<dc><er>

**Valid Values:** d degrees (default)  
m mils

**Query Syntax:** uc?<es>

## ut (Temperature Units)

Sets the temperature units to either Fahrenheit or Celsius. Temperature output is not available on all modules. Refer to the specific module data sheet for more information.

**Syntax:** ut<aq><es>

**Response Format:** \$ut={value}\*<dc><er>

**Valid Values:** f Fahrenheit (default)  
c Celsius

**Query Syntax:** ut?<es>

## MODULE COMMANDS

### cc (Clear Calibration Data)

Clears the previous calibration information. Refer to the specific module data sheet for more information.

*Note: For modules that do not have an onboard processor (for example, the MicroMag), the CommBoard will calculate and output this data*

**Syntax:** cc<es>

**Response Format:** \$cc\*<dcs><er>

### damping (Digital Damping Enable)

Enables digital damping on the compass heading output. Refer to specific module data sheet for more information.

*Note: For modules that do not have an onboard processor (for example, the MicroMag), the CommBoard will calculate and output this data*

**Syntax:** damping<aq><es>

**Response Format:** \$damping = {value} \* <dcs> <er>

**Valid Values:**

d	disabled (default)
e	enabled

**Query Syntax:** damping?<es>

**dampsize (Digital Damping Sample Size)**

Sets the value for the digital damping of the compass heading output. Refer to specific module data sheet for more information.

*Note:* For modules that do not have an onboard processor (for example, the MicroMag), the CommBoard will calculate and output this data

**Syntax:** dampsize<aq><es>

**Response Format:** \$dampsize=nn\*<dcs><er>

**Valid Values:** nn 1 – 8 for the MicorMag (1 is the default)  
1 – 8 for the V2Xe (1 is the default)

**Query Syntax:** dampsize?<es>

**mag\_dec (Declination Value)**

Sets the declination offset for a reading of True North. Based on the setting of the Compass Units (**uc**) command. Positive declination is easterly declination and negative is westerly declination. This is not applied until True North is set to true.

Declination, also called magnetic variation, is the difference between true and magnetic north, relative to a point on the earth. It is measured in degrees east or west of true north. Correcting for declination is accomplished by storing the correct declination angle, and then changing the heading reference from magnetic north to true north. Declination angles vary throughout the world, and change very slowly over time. For the greatest possible accuracy, go to the National Geophysical Data Center web page below to get the declination angle based on your latitude and longitude: <http://www.ngdc.noaa.gov/cgi-bin/seg/gmag/fldsntnl.pl>

*Note:* For modules that do not have an onboard processor (for example, the MicroMag), the CommBoard will calculate and output this data

**Syntax:** mag\_dec<aq><es>

**Response Format:** \$mag\_dec=nnn\*<dcs><er>

**Valid Values:** nnn = ±180 **If** uc = d, then mag\_dec is in degrees (default is 0)  
nnn = ±3200 **If** uc = m, then mag\_dec is in mils (default is 0)

**Query Syntax:** mag\_dec?<es>

## mpcal (Multi-Polled Calibration Enable)

Enables the multi-polled calibration.

*Note:* For modules that do not have an onboard processor (for example, the MicroMag), the CommBoard will calculate and output this data

### *2-Axis Compass Calibration using the CommBoard*

Calibration is the process used with PNI sensor technology to separate the earth's magnetic field from magnetic field distortions. Magnetic field distortions are created by the environment into which the sensors are mounted. By implementing a simple calibration routine with the sensors in a fixed position within the host system, the maximum and minimum strength fields can be determined and then used to correct the sensor output for the distortions present. A calibration should be performed under the following conditions:

- when the unit is first installed into a host system.
- when the unit is moved.
- when the unit indicates that it is in need of a calibration.

Follow the steps below to perform a calibration.

1. Place the unit to be calibrated into the host system.
2. Set the unit at its intended operating position in as level of a position as possible.
3. Send the Multi-Polled Calibration Enable (mpcal=e) command. This enables the calibration routine.
4. Send the Go Command
5. Rotate the unit through two 360 degree circles while maintaining a level position. The rotations should be no faster than 30 seconds each to achieve the highest possible accuracy.
6. Send the h command
7. Send the Multi-Polled Calibration Disable (mpcal=d) command. This disables the calibration routine.
8. Send the Save Settings (save) command to save the calibration information to the CommBoard and the attached module, where applicable.

**Syntax:**                   mpcal<es>

**Response Format:**       \$mpcal{value}\*<dcs><er>

**Valid Values:**           d       disabled (default)  
                          e       enabled

**Query Syntax:**           mpcal?<es>

## ps (ASIC Period Select)

Sets the value for the ASIC period select. The lowest setting (/32) will provide the fastest response, but the lowest resolution. The highest setting will provide the slowest response, but the highest resolution. Refer to specific module data sheet for more response times and maximum setting allowed.

**Syntax:** ps<aq><es>

**Response Format:** \$ps=n\*<dc><er>

**Syntax:**

n =	=0	=/32
	=1	=/64
	=2	=/128
	=3	=/256
	=4	=/512 (default)
	=5	=/1024
	=6	=/2048
	=7	=/4096

**Query Syntax:** ps?<es>

## save (Save Settings)

Saves the configuration parameters to the CommBoard and attached module (where applicable). Also used to save calibration coefficients to the CommBoard and attached module (where applicable)

**Syntax:** save<aq><es>

**Response Format:** \$save\*<dc><er>

## sn (North Mode)

Used to set either True or Magnetic North. If the value is set to true, then declination is applied to get the True North heading.

*Note: For modules that do not have an onboard processor (for example, the MicroMag), the CommBoard will calculate and output this data*

**Syntax:** sn<aq><es>

**Response Format:** \$sn={value}\*<dc><er>

**Valid Values:** m magnetic (default)  
t true

**Query Syntax:** sn?<es>

## be (Big Endian)

Used to set the endianism of multi-byte parameters (Float32, Uint32, SInt32). If enabled, all parameters communicated between the module and the CommBoard are assumed to be big endian, if disabled they are assumed to be little endian

*Note: For modules that do not have an onboard processor (for example, the MicroMag), the CommBoard will calculate and output this data*

**Syntax:** be<aq><es>

**Response Format:** \$be={value}\*<dc><er>

**Valid Values:** e enabled (default)  
d disabled

**Query Syntax:** be?<es>

## SPI INTERFACE TO SENSOR MODULE

**Table 14: SPI Pin Descriptions**

Pin	Name	Description
1	SCLK	Serial clock output for the SPI port
2	MISO	Serial data input. Master In Slave Out
3	MOSI	Serial data output. Master Out Slave In
4	SSNOT	Active low chip select for SPI port
5	DRDY	Data ready input (not supported by V2Xe module)
6	SYNC	Sync output
7	GND	Ground
8	GIO0	Reserved I/O
9	GIO1	Reserved I/O
10	GIO2	Reserved I/O
11	GIO3	Reserved I/O
12	VDD	Supply voltage, 3 VDC regulated
13	VCC	Unregulated CommBoard input supply voltage
14	GND	Ground

### *SPI Port Pin Descriptions*

#### **MOSI – Master Out Slave In**

The data sent from the CommBoard. Data is transferred most significant bit first. The MOSI line will accept data once the SPI is enabled by taking SSNOT low. Valid data must be presented at least 100 nS before the rising edge of the clock, and remain valid for 100 nS after the edge. New data may be presented to the MOSI pin on the falling edge of SCLK.

#### **SSNOT - Slave Select Line**

Selects the module as the operating slave device. The SSNOT line must be low prior to data transfer and must stay low during the entire transfer. Once the command byte is received by the module, and the module begins to execute the command, the SSNOT line can be deselected until the next SPI transfer.

#### **SCLK – Serial Clock**

Used to synchronize both the data in and out through the MISO and MOSI lines. SCLK is generated by the CommBoard. SCLK should be 1 MHz or less. The CommBoard is configured to run as a master device, making it an output. One byte of data is exchanged over eight clock cycles. Data is captured by the CommBoard on the rising edge of SCLK. Data is shifted out and presented to the module on the MOSI pin on the falling edge of SCLK.

#### **MISO – Master In Slave Out**

The data sent from the module to the CommBoard. Data is transferred most significant bit first. The MISO line is placed in a high impedance state if the slave is not selected (SSNOT = 1).

## ***SPI Hardware Handshaking Line Descriptions***

### **SYNC**

SYNC is usually low. SYNC must be toggled from low-high-low. This is the SPI reset. This line is used to reset the SPI slave when communications get out of synchronization. SYNC is normally used during the module startup.

### **DRDY – Data Ready**

The module returns DRDY. DRDY is low after a SYNC. Once a command has been received and the data is read, DRDY goes high. This is only used with modules that do not have processor.


### ***NOTE:***

*See the applicable PNI module data sheet for specific information on communication and control using the SPI interface*

## ***PNI CommBoard (RS-232 and RS-485)***

### **LED Status Indicators**

1. A live indicator, toggling every 1/2 second.
2. Not used.
3. Not used.
4. On during transition, off when not in transition.



**Figure 2: CommBoard Status Indicators**

## Communication Block Diagram




Figure 3: Block Diagram

## Assembly Views




Figure 4: Side Views




Figure 5: Top View


## Interchangeable Sensor Module

Unless otherwise stated:


- This document pertains to PNI Corporation part number 11867.
- All units are in metric, millimeters.
- Tolerances are  $\pm 0.1$  mm.
- **Table 4** page 5 provides pinout definitions for connector J1.
- **Serial Pin Descriptions (cont).**
  
- Table 6 on page 6 provides pinout definitions for connector J2.
- The alignment arrows in **Figure 6** are defined as pointing in the forward direction.

### CAUTION

During installation, ensure that the white silk-screened arrows on both the stacked board and the CommBoard are pointing towards CommBoard LEDs. Do not misalign or plug the stacked board into the 7-pin headers backwards. Refer to **Figure 6** and to **Figure 7**.




**Figure 6: CommBoard with Module Plugged-In**



**Figure 7: CommBoard with Interchangeable Sensor Module**

- Item 1, CommBoard
- Item 2, Interchangeable Sensor Module



ASSEMBLED VIEW

**Figure 8: Assembled CommBoard**


***Dual In-Line and DB9 Connectors***

Unless otherwise specified:

1. All units are in standard U.S. inches.
2. Cable assembly specifications provided in **Table 15**.
3. The pin descriptions for the DB9 female connector are provided in **Table 16**.
4. The pin descriptions for the Dual In-Line connector are provided in **Table 17**.

**Table 15: Cable Assembly, refer to Callouts on Figure 9**


Item Number	PNI Part Number	Description	Approved Vendor	Vendor Part Number
1	10357	10 conductor 24 AWG stranded (7 x 32)	Belden	9540
2	11772	Crimp housing	FCI	65846-010
3	11710	Strap battery 9 VDC I-style 4" lead	Keystone	2238
4	11712	D-SUB 9 connector, female	JIC	DB-09S-UL
5	11711	Overmold, U-shaped	JIC	HD-09MTL-V
6	11773	Connector crimps	FCI	482510-000



**Figure 9: Cable Assembly**

**Table 16: DB9 Connector Pin Descriptions. Refer to Figure 10**


Pin	Wire	Description
1	not connected	
2	Yellow	TxD (RS-232)
3	Blue	RxD (RS-232)
4	not connected	
5	Green	GND
6	not connected	
7	White	CTS
8	not connected	
9	not connected	



**Figure 10: DB9 Close-up**

**Table 17: Dual In-Line Pin Descriptions. Refer to Figure 11.**

Pin	Wire	Description
1	Yellow	TxD (RS-232)
2	not connected	
3	White or Orange	CTS
4	Blue or Brown	RxD (RS-232)
5	not connected	
6	not connected	
7	not connected	
8	Green	GND
9	Red	Vsupply 5 to 12 VDC
10	Black	GND



**Figure 11: Dual In-Line Connector**

## UNUSED COMMANDS

The following commands are part of the CommBoard programming but are not being used by any of the PNI products currently available for use with the CommBoard.

### **i? (Inclinometer Update)**

**Command Type:** Query Command

Retrieves the inclinometer values.

**Syntax:** i?<es>

**Response Format:** \$Pn.nRn.n=<dc><er>

**Valid Values:** P Pitch  
R Roll

### **z? (Z Axis Sensor Update)**

**Command Type:** Query Command

Retrieves only the corrected Z axis magnetometer values. The Z sensor output is not available on all modules. Refer to the specific module data sheet for more information.

**Syntax:** z?<es>

**Response Format:** \$Zn.n\*<dc><er>

**Valid Values:** n.n

## ep (Pitch Data Enable)

**Command Type:** Configuration Command

Enables the pitch data output.

**Syntax:** ep<aq><es>

**Response Format:** \$ep={value}\*<dc><er>

**Valid Values:**

e	enabled
d	disabled (default)

**Query Syntax:** ep?<es>

## er (Roll Data Enable)

**Command Type:** Configuration Command

Enables the roll data output.

**Syntax:** er<aq><es>

**Response Format:** \$er={value}\*<dc><er>

**Valid Values:**

e	enabled
d	disabled (default)

**Query Syntax:** er?<es>

## ui (Inclinometer Units)

**Command Type:** Configuration Command

Sets the inclinometer units to either degrees or mils.

**Syntax:** ui<aq><es>

**Response Format:** \$ui={value}\*<dc><er>

**Valid Values:** d degrees (default)  
m mils

**Query Syntax:** ui?<es>

## cclip (Inclinometer Clip Value)

**Command Type:** Module Command

Sets the clipping value for the maximum positive and negative angle of the inclinometer. When the inclinometer angle exceeds this value, it is clipped to the set value along with an out of range flag.

**Syntax:** cclip<aq><es>

**Response Format:** \$cclip=nn.n\*<dc><er>

**Valid Values:** nn.n 0 to maximum tilt value allowed by the module (0 is default)

**Query Syntax:** cclip?<es>

## lc (Last Calibration Score)

**Command Type:** Module Command

Retrieves the last calibration score. This option is based on the calibration score of the PNI Corporation's TCM2 module and is not available on all modules. Refer to the specific module data sheet for more information.

**Syntax:** lc? <es>

**Response Format:** \$HnVnMn.n\*<dcs><er>

**Valid Values:** n is equal to the score value.

Hn 0 – 9

Vn 0 – 9

Mn.n >0