KISTER

measure. analyze. innovate.

Femur Load Cell

Uniaxial

Type M505A1A... is designed to measure forces in the femur of the crash test dummies HIII-50 %, HIII-95 %, HIII-5 %, E1, E2 and SID IIs.

- Measuring range 13,5 kN
- ID module integrable
- · Low linearity errors and hysteresis
- Kistler system cabling
- Polarities according to SAE J211/1

Description

The load cell is made of elements on which forces are transmitted. The mechanical deformation element, applied with strain gage, serves for mechanical electrical deformation. The forces to be measured create mechanical stretches and buckling in the gaging member.

Line-up of equivalent load cells:

	Туре
Kistler	M505A1A
FTSS	IF-604
Denton	2121A

In order to avoid linearity errors, the deformation paths are constructively held small (high stiffness). Thus a proportional behavior is realized. The force proportional resistance variations are measured by a Wheatstone-type bridge circuit.

The load cell is available with ID modules, either a UPS module (Universal Parameter Memory) or a Dallas module can be chosen for this functionality. These modules are integrated in an external housing in the wiring or in the connector. Customized cable lengths and connectors with specific pin assignments are optionally available.

Type M505A1A...



Type M505A1A...

Technical Data

Axial Data Fz

Measuring range	kN	13,5
Bridge output voltage	mV/V	1,4
Sensitivity	μV/V/kN	104
Bridge resistance	Ω	350
Ultimate load	%	150

General Data

Supply voltage		
without ID module	VDC	5 15
with ID module	VDC	9 12
Insulation resistance ¹⁾	ΜΩ	>9
Operating temperature range	°C	-20 80
Storage temperature range	°C	-30 90
Amplitude non-linearity	%	<0,5
Hysteresis	%	<0,5
Weight	grams	635

All specifications are typical at 25 $^{\circ}\text{C}$ and rated at 10 V sensor supply voltage, unless otherwise specified.

Page 1/2

¹⁾ All wires to screen (GND), measured with 10 VDC



measure. analyze. innovate.

Application

Type M505A1A... is designed to measure forces in the femur of the crash test dummies HIII-50 %, HIII-95 %, HIII-5 %, E1, E2 and SID IIs.





Fig. 1: Dummy application, location femur






Fig. 2: Dimensions

Included Accessories

• None

Optional Accessories

• Add. label, customized

• ID module

• Add. shunt

Type No.

M015KABID on request

on request

©2011 ... 2012, Kistler Group, Eulachstrasse 22, 8408 Winterthur, Switzerland Tel. +41 52 224 11 11, Fax +41 52 224 14 14, info@kistler.com, www.kistler.com Kistler is a registered trademark of Kistler Holding AG.

Page 2/2

This information corresponds to the current state of knowledge. Kistler reserves the right to make technical changes. Liability for consequential damage resulting from the use of Kistler products is excluded.