RS232 Data Communication Ranges: 0-10 to 0-250 inches Industrial Grade

PT5232

Specification Summary:

GENERAL

Full Stroke Ranges	0-2 to 0-50 inches
Electrical Interface	RS232
Format	Hex
Accuracy	$\ldots \ldots \pm$ 0.75 to 0.18% full stroke
Repeatability	see ordering information
Resolution	± 0.003% full stroke
	thermoplastic or stainless steel
	hard-anodized aluminum
Sensor	plastic-hybrid precision potentiometer
Potentiometer Cycle Life	see ordering information
Maximum Cable Velocity • Acceleration	see ordering information
Weight	5 lbs., max.

ELECTRICAL

Input Voltage	9
Input Current	
Baud Rate	
Update Rate	

ENVIRONMENTAL

Environmental Suitability	NEMA 6, IP 67
Operating Temperature	40° to 200°F (-40° to 90°C)
Vibration	p to 10 G's to 2000 Hz maximum

Outline Drawing



Celesco Transducer Products, Inc. 20630 Plummer Street

Chatsworth, CA 91311 tel: 800.423.5483

+1.818.701.2750

fax: +1.818.701.2799



The PT5232, delivers position feedback via RS232 serial communication to your data acquisition or controller system. The PT5232 sends a raw 16-bit position count from 0000 to FFFF (hex). Additionally this device can be set to continuously send data or send data only when polled.

As the internal position sensing element is a precision potentiometer, this transducer maintains current accurate position even during power loss and does not need to be reset to a "home" position.

Output Signal



celesco.com • info@celesco.com

I/O Format:



Important! All communications to/from the transducer are in HEX!

User Commands:

	User Command				Sensor Response			
Description	<cmd></cmd>	<b0></b0>	<b1></b1>	<b2></b2>	<cmd></cmd>	<b0></b0>	<b<sub>1></b<sub>	< ⁸ 2>
Get Sensor Info	0x05	0x00	0x00	0x00	0x05	version ⁽⁴⁾	date ⁽⁵⁾	date ⁽⁵⁾
Get Serial Number	0x15	0x00	0x00	0x00	0x15	serial number ⁽³⁾		
Start Continuous Data	0x25	0x00	0x00	0x00	0x25	0x00	0x00	0x00
Stop Continuous Data	0x35	0x00	0x00	0x00	0x35	0x00	0x00	0x00
Get Position Data	0x45	0x00	0x00	0x00	0x45	$CMC^{(1)}$	$CMC^{(1)}$	status ⁽²⁾

⁽¹⁾CMC - Current Measurement Count (Position)

The Current Measurement Count (CMC) is the output data that indicates the present position of the measuring cable.

The CMC is a 16-bit value that occupies the first two bytes (B_0 and B_1) of the data field. B_0 is the MSB (most significant byte) and B_1 is the LSB (least significant byte).

The CMC starts at 0000H with the measuring cable fully retracted and continues upward to the end of the stroke range stopping at FFFFH. This holds true for all ranges.

(2)Status

The status byte is used as a flag to indicate the validity of the position signal that the internal electronics receives from the potentiometer.

Flags are as follows:

0x00 = GREEN, 0x55 = YELLOW, 0xAA = RED

A "green" flag shows everything OK. A "yellow" or "red" flag indicates that the sensor has either been extended beyond its range or that there is a problem with the potentiometer.

⁽³⁾Serial Number

Each sensor has it's own unique serial number. This information can be retrieved by sending the sensor the "Get Serial Number" command.

The serial number is a 3 byte value from which ranges from 0 to 9999999 (decimal).

(4) Version

This is a single byte value (0-255 decimal) which indicates the currently installed firmware version of the sensor.

(5) Date

This is a 2 byte value showing the date of currently installed firmware. This value ranges from 01011 - 12319 (decimal). Format is MMDDY. While the month and day are expressed as two digit numbers the year is expressed in a single digit only.

Example: 08054 = August 5, 2004

RS232 Controller Board and DIP Switch Location



Baud Rate

The baud rate can be set using switches **7** & **8** on the 8-pole DIP switch found on the rs232 controller board located inside the transducer.

DIP-7 DIP-8 baud rate



celesco

celesco.com • info@celesco.com

tel: 800.423.5483 • +1.818.701.2750 • fax: +1.818.701.2799

98 | PT5232

SUNSTAR传感与控制 http://www.sensor-ic.com/ TEL:0755-83376549 FAX:0755-83376182 E-MAIL:szss20@163.com

Ordering Information:





version: 3.0 last updated: July 10, 2008

tel: 800.423.5483 • +1.818.701.2750 • fax: +1.818.701.2799

celesco.com • info@celesco.com

celesco

200

200 in.

.18%

.02% 250,000 cycles

0.062 in.

BK

back

0

.79 [20.1]

0

40 [10.2]

inches [mm]

(1,57 mm) dia.

V62

250

250 in.

.18%

.02%

21 ounces

120 in./sec • 2 G's

PT5232 | 99 SUNSTAR传感与控制 http://www.sensor-ic.com/ TEL:0755-83376549 FAX:0755-83376182 E-MAIL:szss20@163.com