

RPI-1391

Sensors

Photointerrupter, encased type

RPI-1391

The RPI-1391 is a transmissive-type photointerrupter that uses a photo IC. A positioning pin is provided on the external case to allow precise snap-in mounting on the PC board.


● Applications

Optical control equipment

● Features

- 1) Small slit width (0.5mm) for high precision.
- 2) Fast response.

● External dimensions (Units : mm)



● Absolute maximum ratings ($T_a=25^{\circ}\text{C}$)

	Parameter	Symbol	Limits	Unit
Input(LED)	Forward current	I_F	50	mA
	Reverse voltage	V_R	5	V
	Power dissipation	P_D	80	mW
Output (photo-transistor)	Power supply voltage	V_{CC}	17	V
	Output voltage	I_O	20	mA
	Power dissipation	P_D	80	mW
Operating temperature	T_{OPR}		-20~+85	$^{\circ}\text{C}$
Storage temperature	T_{STG}		-40~+100	$^{\circ}\text{C}$

Sensors

●Electrical and optical characteristics ($T_a=25^\circ\text{C}$)

	Parameter	Symbol	Min.	Typ.	Max.	Unit	Conditions
Input characteristics	Forward voltage	V_F	—	1.3	1.6	V	$I_F=50\text{mA}$
	Reverse current	I_R	—	—	10	μA	$V_R=5\text{V}$
Output characteristics	Power supply voltage	V_{CC}	4.5	5	17	V	—
	Output low level voltage	V_{OL}	—	0.14	0.4	V	$V_{CC}=5\text{V}, I_{OL}=16\text{mA}$
	Output high level voltage	V_{OH}	3.5	—	—	V	$V_{CC}=5\text{V}, R_L=1\text{k}\Omega$
	Low level power supply current	I_{CL}	—	1.8	5.0	mA	$V_{CC}=5\text{V}$
	High level power supply current	I_{CH}	—	1.7	3.0	mA	$V_{CC}=5\text{V}$
	Low → High Threshold input current	I_{FLH}	—	1.3	5.0	mA	$V_{CC}=5\text{V}$
Transfer characteristics	Hysteresis	I_{FHL} / I_{FLH}	—	0.7	—	—	$V_{CC}=5\text{V}$
	Low → High Propagation delay time	t_{PLH}	—	1.6	—	—	$V_{CC}=5\text{V}, I_F=10\text{mA}, R_L=680\Omega$
		t_{PHL}	—	2.2	—	μs	
	Rise time	t_r	—	0.28	—	—	
	Fall time	t_f	—	0.12	—	—	

●Electrical and optical characteristic curves




Fig.1 Forward current falloff




Fig.2 Forward current vs. forward voltage




Fig.3 Power dissipation vs. ambient temperature




Fig.4 Low level output voltage vs. low level output current




Fig.5 Low level output voltage vs. ambient temperature




Fig.6 Supply current vs. supply voltage

ROHM

Sensors




Fig.7 Rise and fall time vs. load resistance




Fig.8 Relative output voltage vs. distance




Fig.9 Response time measurement circuit

ROHM